



## Assembly Instructions

### AM-9 Pedal Leveler

#### TOOLS REQUIRED

10mm wrench or socket

- 1) Insert 10 mm self tapping bolt through washer and then through eyelet of pulley.
- 2) Using either a 10mm wrench or socket thread 10mm self tapping bolt into hole on underside of rear frame of AM-9S or AM-9XS.
- 3) Thread cord through pulley and insert each end into slotted hole on underside of pedal plate, tie knot in cord to keep it from pulling through.
- 4) Tension cord so that pedals are level.

