

Chain Tensioner Replacement



If you have received the new style chain tensioner it is due to a recall notice that you received in the mail. Please follow instructions below.

- 1) Remove original chain tensioner using a 13mm wrench or socket. Securing nuts are on the backside of tensioner.
- 2) Turn chain tensioner clockwise (RIGHT) to loosen chain. Remove chain tensioner and throw away.
- 3) Install new chain tensioner that you received, making sure chain is install just like picture above.
- 4) Turn chain tensioner counter clockwise (Left) to tighten chain. Once chain is tight while hole tensioner in place tighten the two 13mm nuts located on the back with a wrench or socket.
- 5) Before riding the tryke try twisting the chain tensioner in either direction making sure it is securley tightened.